



Ice Hopper Extension for BluBear

Model No. 2748-00-000

Attaching the Optional Ice Hopper Extension

The optional Ice Hopper Extension increases the potential ice holding capacity of the BluBear hopper to approx. 12 lbs. Follow the instructions below to install the hopper extension on a BluBear Ice Shaver (2747 Series, sold separately).

Important: Do Not Drop. Ice chute is made of an acrylic material—handle with care.


Step 1: Turn ice shaver power switch OFF and unplug unit before attempting to install the Ice Hopper Extension.

Step 2: Remove top cover by removing the 4 thumb screws (save for reuse), then lift top cover off unit.



Remove 4 Thumb Screws then remove Top Cover.

Ice Chute (clear acrylic)



Magnet View


Lid Momentary Switch Location



Step 3: Align Ice Hopper Extension with ice shaver – MAKE SURE the magnet is positioned over the lid momentary switch.

BluBear **WILL NOT WORK** if hopper extension is not positioned to engage the lid momentary switch.

Lid



Fill Line Label for adding ice (label should face operator).

Fasten Thumb Screws

Step 4: Re-fasten the 4 thumb screws to secure.

To use: Add ice to Fill Line (indicted on label) then put lid on tube.



Parts List



Item	Part Description	Part Number
		2748-00-000
1	LID	100289
2	ICE CHUTE	12997
3	DECAL, SHAVE ICE	68762
4	FILL LINE DECAL, MAXIMICER	12645
5	WARNING, SHARP BLADES	12062S
6	THUMB SCREW 1/4-20 X 3/4	38379
7	ICE EXT BASE WELD ASSY	115207
8	8-32 X 3/8 PAN HD PH M/S (fastens magnet holder)	12389
9	BLUE-ICER MAGNET HOLDER	115208
10	MAGNET USES 8 FLT HD SC	50013
11	8-32 X 3/4 PHIL FLAT M/S (fastens magnet)	47125